INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES MOTORCYCLE COVER

ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the warranty information and procedure for properly installing Drag Specialties motorcycle cover.

Review these instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A **NOTE** provides key information to make procedures easier or clearer.

CAUTION: A **CAUTION** indicates special procedures that must be followed to avoid damage to the motorcycle and/ or accessories.

WARNING!: A **WARNING** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

PLEASE READ:

IMPORTANT WARRANTY INFORMATION

Drag Specialties motorcycle covers are warranted from defects in material and workmanship for a two-year period from the date of purchase. All honored claims during this warranty period may result in free repair or replacement. Repair or replacement will be done at the discretion of the manufacturer.

Covers are not designed for the purpose of trailering. Trailering will void warranty.

Misuse or abuse will void warranty. No warranty claims shall exceed the price of the cover. LeMans Corporation will not be liable for any consequential or incidental damage.

All warranty claims must include the original proof of purchase along with the Drag Specialties manufacturer's label; otherwise warranty may be voided.

ATTENTION: Removal of care label on product voids any implied warranty. Should you have a warranty problem or question, **DO NOT CONTACT THE DEALER**. Email coverhelp@DragSpecialties.com or call LeMans Seat Company, 19140 Linden Drive, P.O. Box 265, Rogers, MN 55374, (763) 428-8377.

CAUTION: Allow pipes to cool before installing cover.







INSTALLATION: Locate the label on the bottom hem of the cover that reads REAR. Position the cover over the motorcycle with the design positioned over the windshield or handlebar area. Slip the cover over the handlebars and pull down around the motorcycle.

CARE INSTRUCTIONS: Do not machine wash or dry covers. Hose the covers off and use mild soap and dry on a clothesline.

CAUTION: DO NOT use plastic or non-breathable tarps over your Drag Specialties motorcycle cover. These tarps will trap moisture and promote rotting.

CAUTION: This cover is not intended for seasonal/long-term storage.

