

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES LOW SOLO SEAT FOR 04-PRESENT SPORTSTER®

ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing Drag seats onto 04-present Sportster® models. Review these instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations.

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING!: A **WARNING** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.



TOOLS REQUIRED:
#3 Phillips screwdriver

PROCEDURE:
Begin by placing the bike on the side stand.

1. Remove the stock seat from the bike. Save the rear Phillips-head screw.

NOTE: On models with a two-passenger seat, the rear fender nut must be relocated. On models that came with a factory solo seat, it may be necessary to relocate the fender nut based on the style of your new seat.

RELOCATING THE FENDER NUT:

NOTE: Your fender will have three nut locations: forward, center and rear. Your new solo will mount to the most forward or center location. Determine the location for your particular seat at this time. If the fender nut requires relocation, proceed to **STEP A**.

- A) Remove the E-clip and the nut from its current location.
- B) Remove the plastic cap from the new location for your particular seat.
- C) Reinstall the nut in the new location and the plastic cap in the previous location.

2. Loosen the rear bracket on your new seat, so it moves with some resistance.
3. Install your seat over the tab at the front of the frame, near the gas tank and position on the rear fender. Slide the seat forward and adjust the rear bracket to align with the mounting nut in the fender.
4. Remove the seat, tighten the rear bracket and reinstall the seat using the stock mounting screw.

Sportster® is a registered trademark of the Harley-Davidson Motor Company, Inc., Milwaukee, WI USA.

