

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES SIDE PLATES & SISSY BARS P/N DS-263623

ATTENTION INSTALLER: (if other than owner): Please forward this instruction sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing Drag Specialties Sissy Bars with these Side Plates onto 80-86 FXWG and 84-96 FXST models.

Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: (shaded) A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING: (boxed and shaded) A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.



TOOLS REQUIRED:

9/16" combination wrench
5/32" hex key

PROCEDURE:

1. Attach the Sissy Bar to the Side Plates, using the button head screws provided. These screws should be installed through the outside of the Side Plates.

2. Remove the two center OEM bolts holding the fender to the fender braces on each side.

3. Slide the complete assembly onto the outside of the fender braces.

4. On 80-86 FXWG models use all the original hardware.

5. On 84-85 FXST models use the original rear 3/8-16 x 1 1/4" screws in the front positions. Use the provided 3/8-16 x 1 1/2" hex head screws in the rear positions.

6. On 86-96 FXST models, attach using the provided 3/8-16 x 1 1/2" hex head screws.

7. Tighten SECURELY.

WARNING! Before operating motorcycle, be sure all hardware is tight.

DRAG SPECIALTIES

Box 9336, Minneapolis, MN 55440