

# INSTALLATION INSTRUCTIONS

## DRAG SPECIALTIES OVAL SISSY BAR PAD P/N 0822-0117, 0822-0118

**ATTENTION INSTALLER** (if other than owner): Please forward this instruction sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

**INTRODUCTION:** These instructions describe the procedure for properly installing Drag Specialties sissy bar pads.

Review these instructions carefully before beginning, as they contain important information. Please retain for future reference.

**NOTE: A NOTE** provides key information to make procedures easier or clearer.

**CAUTION: A CAUTION** indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

**WARNING!: A WARNING** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

### SOLAR REFLECTIVE TECHNOLOGY

Solar reflective leather keeps the contact area cool, even in direct sunlight. The process has been shown to reduce surface temperatures by as much as 25°F.

**NOTE:** The Solar Reflective Technology is only available on select pads. See the catalog for specific applications.

**CAUTION:** The use of leather conditioners or chemicals will void the warranty.

**CLEANUP:** Warm water, mild soap and a soft cloth should be used for cleanup.

**NOTE:** This pad does not contain mounting hardware. Requires OEM docking hardware.

### PROCEDURE:

1. Remove the three screws, pad bracket and three spacers for the pad or docking hardware kit.
2. Install the three spacers into the new sissy bar pad. Assemble to the sissy bar. Align the pad to the bar.

**CAUTION:** Do not over-tighten screws.

