

# INSTALLATION INSTRUCTIONS

## DRAG SPECIALTIES DRIVER BACKREST PAD FOR INDIAN SCOUT OEM BACKREST BAR

**ATTENTION INSTALLER** (if other than owner): Please forward this Instruction Sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

**INTRODUCTION:** These instructions describe the procedure for properly installing a Drag Specialties backrest pad onto the OEM backrest bar on Indian Scout models.

Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

**NOTE: A NOTE** provides key information to make procedures easier or clearer.

**CAUTION: A CAUTION** indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

**WARNING! A WARNING** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.



### ABOUT THE SOLAR REFLECTIVE TECHNOLOGY

Solar reflective leather keeps the seating area cool even in direct sunlight. The process has been shown to reduce surface temperatures by as much as 25°F.

**NOTE:** The Solar Reflective Technology is only available on select models. See catalog for specific applications.

**CAUTION:** Use of leather conditioner or chemicals will void warranty. Warm water, mild soap and a soft cloth should be used for cleanup.

### HARDWARE:

Pad (1)

Screws, 6mm x 16mm Panhead Phillips, mounted in pad (3)

### INSTALLATION:

1. Remove the three screws from the rear of the pad.
2. Position the pad on the OEM backrest bar and start all three screws. Once the screws are started, turn all three screws all the way in, then tighten.

**NOTE:** Install the backrest bar per the manufacturer's instructions.

