



MOOSE PLOW BOTTOM MOUNT INSTRUCTIONS
2017 POLARIS ACE 900 XC
PART# 4501-0582

QTY.	PART#	DESCRIPTION
1	2817-100	Plow Mount Plate
2	2610-15	Round Spacer
2	2763-2	Spacer Block
2	HDW2124	3/8 x 3-1/2 Hex Bolt
2	HDW7061	3/8 Nylock Nut
2	HDW9218	5/16 x 1-1/2 x 2-3/4 U-Bolt
4	HDW9002	5/16 Flat Washer
4	HDW7058	5/16 Nylock Nut

Remove front skid plate if required.

Attach plow mount to machine as shown in lower Picture.

The back portion will mount up to the frame tube Just in front of the floor board support tube. Use the Spacer block between the frame tube and the mount plate and use the u-bolts to go around frame tube and Through the spacer block and mount and then place the flat washer and nylock nuts on to the u-bolts and only snug up at this time.

The front portion of the mount will attach to some holes in the front frame tubes right between the a- arm mounting points. Use the 5/16 x 3-1/2 hex bolt to go down through the frame, spacer and mount. Make sure the spacer is between the frame and mount and then use the 5/16 nylock nut to secure in place. Now align and tighten all the bolts.

