



**POLARIS RANGER 570 FULL SIZE
PLOW MOUNT INSTRUCTIONS
PART# 4501-0549**

Attach the bottom mount to the underside of machine per picture using the 4 U-Bolts provided in the hardware kit. Use the washers and nylock nuts to secure.

You may have to remove the plastic skid plate if your machine came with one.

To get you bolts up around the frame tube it may be required to push up in the floor board plastic to slide them up and over the frame tube.

After you use the plow for a while you should go back and re-tighten the u-bolts.

Never exceed more the 5mph or hit and hard or frozen objects while plowing as this may cause damage or bodily injury and void any and all warranty.

For any questions or comments please call :
763-689-4800

QTY.	PART#	DESCRIPTION
1	2785-100	Bottom Mount Plate
4	HDW9060	5/16 x1-1/2 x 4 U-Bolt
8	HDW7058	5/16 Nylock Nut
8	HDW9002	5/16 Flat Washer



