

# INSTALLATION INSTRUCTIONS

## DRAG SPECIALTIES FENDER SKINS FOR 2018 SOFTAIL MODELS

**ATTENTION INSTALLER** (if other than owner): Please forward this Instruction Sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

**INTRODUCTION:** These instructions describe the procedure for properly installing Drag Specialties Fender Skins

Review these instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

**NOTE: A NOTE** provides key information to make procedures easier or clearer.

**CAUTION: A CAUTION** indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

**WARNING!: A WARNING** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

**NOTE:** Follow instructions carefully to ensure a good fit.

Provided in your kit:

- A.  $\frac{5}{16}$ " punch
- B.  $\frac{1}{4}$ " Black zinc washer
- C.  $\frac{1}{4}$ " Black zinc button-head screw

**CAUTION:** If it becomes necessary to shorten the length of your Fender Skin, always seal the threads with hot melt glue or contact adhesive. Allow to dry prior to trimming.

1. If your Softtail has a rear solo, remove at this time. The rear screw will not be re-used.

**NOTE:** If your model came with a solo front only, it will be necessary to purchase a rear fender nut to mount the Fender Skin (Drag Specialties PART # DS-490045 or OEM # 59768-97).

2. Remove the front solo seat.
3. Mount your Fender Skin using the recommended screw and washer. **SEE CAUTION ABOVE.**



4. Pull the Fender Skin slightly forward and center left to right. Maintain slight tension, mark the location of the hole in the fender with chalk. Measure the Fender Skin to make sure the hole is centered correctly. Remove the Fender Skin.
5. Now that the hole location is marked on the Fender Skin, place a piece of wood or rigid plastic behind the hole, place punch over marked area, and while holding with pliers, strike a hammer to punch the hole. Before punching a second hole (if needed), clear material from punch.
6. Reinstall the Fender Skin and solo seat.

