

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES TOUR BOX PAD 2014 - UP

ATTENTION INSTALLER (if other than owner): Please forward this Instruction Sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing Drag Specialties Tour Box Pads.

Review these instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING! A WARNING! indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

ABOUT SOLAR REFLECTIVE LEATHER

Solar reflective leather keeps the seating area cool even in direct sunlight. The process has been shown to reduce surface temperatures by as much as 25°F.

NOTE: The Solar Leather technology is only available in select models. See catalog for specific applications.

CAUTION: Use of leather conditioners or chemicals will void warranty.

CLEANUP: Warm water, mild soap and a soft cloth should be used for cleanup.

REMOVAL PROCEDURE:

1. Open the Tour Box and remove the three hex nuts that fasten the pad to the lid. Remove the pad. These hex nuts will not be reused.

INSTALLATION PROCEDURE:

Your new Tour Box pad comes with all hardware attached. Remove the three rubber caps, washers and hex nuts. Do not remove rubber bumpers. Note locations of mounting holes in the lid. You will be using the two outermost holes and the upper center hole.

1. With rubber bumper on each stud, line up mount studs with the box holes working from side to side, ensuring all studs are through all three holes.
2. Place one washer and hex nut on each stud, tighten securely. Install rubber cap.



0822-0354



0822-0356



0822-0357

