

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES FULL-LENGTH SEATS FOR 2018-UP SOFTAIL MODELS

ATTENTION INSTALLER (if other than owner): Please forward this Instruction Sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing the replacement Drag Specialties speedometer on 2004 and later models. Review these instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A **NOTE** provides key information to make procedures easier or clearer.

CAUTION: A **CAUTION** indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING!: A **WARNING** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

ABOUT THE SOLAR REFLECTIVE TECHNOLOGY

Solar reflective leather keeps the seating area cool even in direct sunlight. The process has been shown to reduce surface temperatures by as much as 25°F.

NOTE: Solar Reflective technology is only available on select models. See catalog for specific applications.

CAUTION: The use of leather conditioners or chemicals will void warranty.

CLEANUP: Warm water, mild soap and a soft cloth should be used for cleanup.

MOUNTING HARDWARE

*490015A Bracket 1

*424130 Screw 2

* = Mounted on the seat

PROCEDURES:

1. Begin by placing the bike on the side stand.
2. Remove the stock seat from the bike. Save the rear seat screw. It will be reused.

NOTE: ON HERITAGE CLASSIC AND DELUXE MODELS

3. Loosen the rear bracket on your new seat, so it moves with some resistance.

The two thumb nuts securing the solo front will not be reused. INSTALL THE TWO 1/4" x 20 FLANGE NUTS PROVIDED TO SECURE STUDS IN THE FENDER. ON DELUXE MODELS A 1/4" x 20" x 3/4" SCREW WILL NEED TO BE PURCHASED TO FASTEN REAR OF SEAT TO FENDER.

0802-1130



0802-1073



NOTE: ON SLIM AND STREET BOB MODELS

The fender nut in the solo location will need to be relocated prior to installing your one-piece seat.

PROCEDURE: Remove the plastic cap from the seat mount hole furthest back on the fender and save it. Remove the E-clip and nut from the current solo seat mount location and reinstall it into the rear seat mount hole. Install the plastic cap into the forward seat mount location.

4. Slip your new seat over the tab at the front of the frame near the gas tank and position it over the rear fender.
5. With the seat centered (make sure the seat is forward), position the rear seat bracket to line up with the hole in the fender. Remove the seat and tighten the fasteners holding the bracket.
6. Slip the seat onto the front frame tab and attach the rear bracket to the fender, reusing the stock mounting screw.

Softail™ is a registered trademark of Harley-Davidson® Motor Company, Inc., Milwaukee, WI, U.S.A.



3501 Kennedy Rd, PO Box 5222, Janesville, WI 53547-5222
P/N 010412