

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES CHOPPED TOUR PACK PAD FOR CUSTOM APPLICATIONS

ATTENTION INSTALLER (if other than owner): Please forward this Instruction Sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing Drag Specialties Chopped Tour Pack Pads.

Review these instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING! A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.



ABOUT SOLAR REFLECTIVE LEATHER

Solar reflective leather keeps the seating area cool even in direct sunlight. The process has been shown to reduce surface temperatures by as much as 25°F.

NOTE: The Solar Leather technology is only available in select models. See catalog for specific applications.

CAUTION: Use of leather conditioners or chemicals will void warranty.

CLEANUP: Warm water, mild soap and a soft cloth should be used for cleanup.

INSTALLATION PROCEDURE

1. Using the supplied template, mark the pad location on the outside of the tour box.
2. Remove the three screws and washers from the back of the pad. Place the pad over the marked locations to insure it is centered and at the correct height.
3. Using a 1/4" drill bit, drill the three holes.
4. Install the pad and tighten the three screws. Do not overtighten.

NOTE: If installing the optional lower pad, position between upper pad and tour box during assembly.

