



RM5 PLOW MOUNT INSTRUCTIONS
KAWASAKI MULE FX / FXT / FXR
PART# 4501-0588

ITEM	PART#	QTY.	DESCRIPTION
1	4495-70	1	PLOW MOUNT
2	HDW2065	2	5/16 x 4-1/4 x 2-3/4 Square U-Bolt
3	HDW7058	4	5/16 Nylock Nut
4	HDW9002	4	5/16 Flat Washer
5	HDW2100	2	3/8 x 1 Hex Bolt
6	HDW7061	2	3/8 Nylock Nut
7	HDW9001	4	3/8 Flat Washer

Place the 5/16 x 4-1/4 x 2-3/4 square U-bolts around the front bumper tubes as shown in picture.

Hold the plow mount up in place and onto the U-bolts and use the 5/16 washer and nylock nuts to attach.

Swing the back portion of the mount up to the frame and should align with a couple holes. Use the 3/8 x 1 hex bolts with washer and the washer and nylock nut on the inside to attach.

Tight all bolts securely.

NOTE: Push tubes will pin up with the wire loop pins that came with the push tube kit.

Watch on how far you can lift your plow and do not over lift or you may cause severe damage to the unit and or machine.

Question or Comments Call
 320-964-1616
 Monday – Thursday
 7:00 to 4:30 CST

