



Kawasaki
'06-'11 650 Brute Force (IRS),
'05-'12 750 Brute Force

ITEM	PART#	QTY.	DESCRIPTION
1	2740-70	1	Plow Mount Weldment
2	HDW2158	4	5/16 x 1-3/8 x 2-3/16 Rd. U-Bolt
3	HDW9002	8	5/16 Flat Washer
4	HDW7058	8	5/16 Nylock Nut

PART# 4501-0608
PLOW MOUNT INSTALLATION INSTRUCTIONS

Remove the skid plate.

Place the u-bolts over the frame tubes as shown in the illustration.

Place the mount plate up onto the u-bolts and secure with the washers and nylock nuts, align and tighten.

The push tubes will pin up to the ears on the bottom with the pins provided with the push tube.

