



**POLARIS**

05-10 Sportsman 800 / 02-07 Sportsman 700  
05-06 MV7 / 09/11 Trailblazer & Trailboss 330  
03-05 Sportsman 600 / 03-08 Sportsman 500  
07-09 Scrambler 500

ITEM	PART#	QTY.	DESCRIPTION
1	2743-70	1	Plow Mount Weldment
2	HDW2155	4	5/16 x 1-1/8 x 2-1/4 Sq U-Bolt
3	HDW9002	8	5/16 Flat Washer
4	HDW7058	8	5/16 Nylock Nut

**PART# 4501-0610**

Attach plow mount to underside of machine as shown in illustration with tapered end going to the front.

First hang the u-bolts over the frame tubes in there locations.

Place the mount up onto the u-bolts and place the flat washers and nylock nuts on. Align the mount and tighten.

Push tubes will mount to the tabs with the wire loop pins supplied with the push tube assembly.

