



PLOW BOTTOM INSTALLATION INSTRUCTIONS
POLARIS
09-13 SPORTSMAN 550/850 XP

ITEM	PART#	QTY.	Description
1	2745-100	1	Plow Bottom Mount
2	HDW2158	4	5/16 x 1-3/8 x 2-3/16 Rd. U-Bolt
3	HDW9002	8	5/16 Flat Washer
4	HDW7058	8	5/16 Nylock Nut
5	HDW2545	1	8 Inch Black Zip Tie

PART# 4501-0611

Remove the stock skidplate. Use the zip tie in bolt bag to secure the bottom hole of the inner fender to the bottom frame tube. See illustration.

Place u-bolts over frame tube as shown in illustration. Place mount plate up onto u-bolts with narrow end going toward the front of machine.

Secure mount in place with the flat washers and nylock nuts. Make the cut out in mount clears the zip tie you put on for the inner fender as shown in illustration.

The push tube will pin up to the tabs on the bottom mount with the wire loop pins included with push tube.

