



ITEM	PART#	QTY.	DESCRIPTION
1	2746-70	1	Plow Mount Weldment
2	HDW2155	4	5/16 x 1-1/8 x 2-1/4 Sq. U-Bolt
3	HDW9002	8	5/16 Flat Washer
4	HDW7058	8	5/16 Nylock Nut

POLARIS

96-04 Sportsman 500 / 99-02 Magnum 500 / 97 Xplorer 500
99-00 Diesel / 00-02 Xpedition 425 / 01-04 Sportsman 400
95-02 400L & Xplorer / 98-00 Sportsman 335 / 00-01 Magnum
04-08 Trail Boss 330 / 96-99 Xplorer 300 / 00-01 Xplorer 250

PART# 4501-0612

You will mount the plow mount up as the illustration shows with the tabs going toward the front of the machine.

First place u-bolts around frame tubes as shown doing the left side first, then swing mount up to the right side and see which hole you will need to use. Once you bolts are in place align and tighten using the washers and nylock nuts.

Push tube will pin up to tabs on mount with the wire loop pins provided with the push tube.

