



PLOW MOUNT INSTALLATION INSTRUCTIONS
2014 POLARIS ACE

PART# 4501-0617

ITEM	PART#	QTY.	DESCRIPTION
1	2761-100	1	Plow Mount Weldment
2	HDW9218	2	5/16 x 1-1/2 x 2-3/4 Rd. U-Bolt
3	HDW2073	2	5/16 x 1-1/2 x 3-1/2 Sq. U-Bolt
4	HDW9002	8	5/16 Flat Washer
5	HDW7058	8	5/16 Nylock Nut

Remove the factory skid plate. Hang the two square u-bolts in place over the main rectangular frame tubes in front of the horizontal crossmember as shown in picture. Now hang the front round u-bolts in place over the small round frame tubes that come down into the main frame and they will go right in front of round support tube going to the outside as shown in picture. Place bottom mount up onto u-bolts and use the flat washers and nylock nuts to secure. Align and tighten firmly. **NOTE:** You can install over skid plate but you will have to align and mark u-bolt locations and drill you skid plate for u-bolt to come through. Your push tube will pin up to tabs using the wire loop pins that came with push tube kit.



Rear U-Bolt position just in front of the horizontal crossmember.

Front U-Bolt position over the square frame tubes where they are welded to the round frame crossmember.



Front of Machine →



Front of Machine →