



**FLOW MOUNT INSTALLATION INSTRUCTIONS**

**YAMAHA**

**99-01 Grizzly YFM 600**

**PART# 4501-0621**

ITEM	PART#	QTY.	DESCRIPTION
1	2777-70	1	Plow Mount Weldment
2	2777-2	1	Offset Bracket
3	HDW2215	1	1/2 x 1 Hex Bolt
4	HDW7089	1	1/2 Nylock Nut
5	HDW1069	4	10mm x 30MM Hex Bolt
6	HDW9009	4	7/16 Split Lock Washer

**Remove the inner floor board mounting bolts as shown. Keep bolt for use when plow mount is not installed.**

**Attach the plow mount to this location with the push tube tabs toward the front and use the 10mm x 30mm hex boots and 7/16 lock washers to secure. Align and tighten.**

**For the 1999 and new models, install the offset bracket on the right front mounting tab using the 1/2 x 1 bolt and nylock nut provided (as you sit on machine)**

**Push tube will pin up to tabs with the wire loop pins included in the push tube kit.**

