



ITEM	PART#	QTY.	DESCRIPTION
1	2797-70	1	Plow Mount Weldment
2	HDW1056	4	8mm-1.25 x 40mm Hex Bolt
3	HDW9002	4	5/16 Flat Washer

Bombardier
99-05 500 Traxter 4x4, 03-05 500 Traxter Max
05 650 Traxter Max XT 4x4,
02-03 Quest 650/XT 4x4
John Deere
05-06 500 & 650 Tail Buck CVT & XT

PART# 4501-0626

Remove the bottom four bolts that hold the mid-frame skid plate on. Retain to re-install for when bottom mount is removed.

Install the bottom as shown over the top of the skid plate using the (4) 8mm x 40mm Hex bolt and 5/16 flat washers. Tabs should go toward the front of machine.

The push tubes will mount to the tabs with wire loop pins included with push tube kit.

