



KAWASAKI MULE 3010/4010
PART# 4501-0631

ITEM	PART#	QTY.	DESCRIPTION
1	2757-70	1	Plow Mount Weldment
2	HDW2158	4	5/16 x 1-3/8 x 2-3/16 Rd. U-Bolt
3	HDW9002	8	5/16 Flat Washer
4	HDW7058	8	5/16 Nylock Nut

Place the u-bolts over the frame tubes as shown in the illustration. The narrow side of the mount goes toward the front of machine. The front u-bolt will go just behind the differential skid plate, the rear u-bolts will go on the same tube but farther back where it widens. The mount will be at a slight forward angle.

Install the mount onto the u-bolts and secure using the washers and nylock nuts, tighten firmly.

The push tube will pin up to the tabs using the wire loop pins supplied with the push tube.

