



2017 TEXTRON STAMPEDE

PART# 4501-0831

ITEM	PART#	QTY.	DESCRIPTION
1	2828-70	1	Plow Mount Plate
2	HDW2065	4	5/16 x 2-3/4 x 4-1/4 Sq. U-Bolt
3	HDW7058	8	5/16 Nylock Nut
4	HDW9002	8	5/16 Flat Washer

The plow mount will attach right in front of the bottom skid plate. Place the U-bolts up over the Frame as shown in picture. The rear U-bolts will go up against the frame cross member.



Place the mount up in place over the U-bolts. Place the washers and nylock nuts on and lightly tighten. Once the mount is lightly snugged up Push it back till it is against the skid plate and finish tightening.

Push tube will pin up to mount with the wire loop pins provided with the push tube.

