



**YAMAHA WOLVERINE BOTTOM MOUNT
PART# 4501-0832**

ITEM	QTY.	PART#	DESCRIPTION
1	1	2816-100	Plow Mount Plate
2	4	HDW2073	5/16 x 1-1/2 x 3-1/2 Sq U-Bolt
3	8	HDW7058	5/16 Nylock Nut
4	8	HDW9002	5/16 Flat Washer

Attach Bottom Mount Plate to frame tubes as shown in picture with the square U-bolt provided.

Once mount plate is attached align and tighten U-bolts.

You may cut off any extra threads on U-bolts to prevent from being bent or causing interference.

After first use re-tighten the bolts as they may have loosened. Do not over tighten

