



**PLOW BOTTOM MOUNT INSTRUCTION
POLARIS RAMNGER 900/1000
PART# 4501-0871**

ITEM	PART#	QTY.	DESCRIPTION
1	2810-70	1	Bottom plow mount plate
2	HDW2061	4	5/16 x 1-1/4 Hex Bolt
3	HDW7058	4	5/16 Nylock Nut
4	HDW9002	4	5/16 Flat Washer
5	HDW9427	4	1/4 Thick Spacer

The plow mount will mount up as shown and it goes just in front of the cab frame with the back bolt
And the front bolt will go to the tab just in front of the rear A-arm.

When mounting this up the plow mount tabs go to the back.

Make sure you use the 1/4" spacers between the mount and machine as shown.

Align and tighten all bolts securely.

The plow will pin up between the tabs with the wire loop pins provided in the push tube kit.

