



ITEM	PART#	QTY.	DESCRIPTION
1	2831-70	1	Plow Mount Plate
2	HDW2073	4	5/16 x 1-1/2 x 3-1/2 Sq. U-Bolt
3	HDW7058	8	5/16 Nylock Nut
4	HDW9002	8	5/16 Flat Washer

MOOSE PLOW MOUNT INSTRUCTIONS
CF-MOTO U-FORCE 800
PART# 4501-0874

NOTE: If your machine has the large plastic skid plate you will need to remove it or mark where the hole will be for the mount and drill it out to fit mount on outside of skid plate. You will have to leave the front of skid plate loose to get U-Bolts in place.

Mount plate will mount up as shown in picture with the front of the mount going where the frame tubes narrow up. Note the front U-Bolts go over frame tube and through the metal skid plate cross member.

The back U-Bolts will then go over the frame cross tube. Once mount plate is in place use the washers and nylock nuts to secure and then tighten.

Push tube will pin up with the wire loop pins provided with the push tube kit.



Questions or Comments Call 320-964-1616 Monday thru Thursday 7:00 to 4:30 CST

INST2831PF