



**YAMAHA**  
**95-05 350 WOLVERINE 4X4**  
**97-99 BIG BEAR 350 4X4**  
**99 KODIAK 400**  
**00-06 BIG BEAR 400 4X4**

ITEM	PART#	QTY.	DESCRIPTION
1	2776-70	1	Plow Mount Weldment
2	HDW2154	2	5/16 x 1-1/4 x 2 Rd. U-Bolt
3	HDW9002	4	5/16 Flat Washer
4	HDW7058	4	5/16 Nylock Nut
5	HDW1069	2	10mm x 30mm Hex Bolt
6	HDW9009	2	7/16 Split Lock Washer

**PART# 4501-0620**

Remove the front foot peg bolts. Retain for use when bottom mount is not installed.

Install bottom mount by first attaching the mount to the foot peg location where you removed the bolts and use the 10mm x 30mm hex bolts with the 7/16 lock washers in the location.

Swing the bottom mount up to the frame and place the U-bolts over frame tube and down through the mount plate and secure with the flat washers and nylock nuts. Align and tighten firmly.

Push tube will pin up to tabs with the wire loop pins included with the push tube kit.

