



KLR 650 <07 REAR BRAKE CYLINDER GUARD INSTRUCTION

Remove original mounting bolts.

The guard mounts between the frame and the brake cylinder

Install the guard with the included hardware.

Tighten all hardware securely.

Check for interference between the brake arm and/or the swing arm.

Check to make sure that the brake light activates when the brake pedal is depressed.

Any questions or problems contact T C I Products. 714-639-4933

turbo@turbocity.com



KLR 650 <07 REAR BRAKE CYLINDER GUARD INSTRUCTION

Remove original mounting bolts.

The guard mounts between the frame and the brake cylinder

Install the guard with the included hardware.

Tighten all hardware securely.

Check for interference between the brake arm and/or the swing arm.

Check to make sure that the brake light activates when the brake pedal is depressed.

Any questions or problems contact T C I Products. 714-639-4933

turbo@turbocity.com